

Technik

F 650 CS
Lexan® FMR Polycarbonate Windshield
Z2261 Light Tint

Read these instructions carefully and thoroughly before beginning work.

Contents of Kit

Windscreen, Lexan FMR polycarbonate

Qty.

1



Figure 1.



Figure 2.

Tools Required:

TX25 Screwdriver.

INSTALLATION

1. Remove the four original Torx screws from existing BMW windshield. Retain screws. **Figure 1. (TX25 Screwdriver)**
2. Remove the original BMW windshield.
3. Replace windshield with **ZTechnik Windshield. Figure 2.**
4. Reinstall original Torx screws in same location. **(TX25 Screwdriver)**
5. Tighten all hardware.

MAINTENANCE

To clean the screen, wash with a clean soft cloth, plenty of warm water and, if necessary, a non-abrasive soap such as dishwashing liquid. Flannel or soft chamois make good cleaning cloths. **Paint, glue residue or grease removal:** Moisten cotton with Naphtha or Turpentine followed by a wash as above. Apply a high quality plastic cleaner, such as McGuiar's Mirror-Glaze MG-17 or Novus #2, to the screen. This will leave a protective coating on the screen making future cleanings easier. Do not clean polycarbonate in hot sun or high temperatures.

Do not clean the screen with glass cleaners. Do not use rain protective products on the screen. The solvent action of the alcohol in these products will destroy the screen. Do not allow brake fluid, alcohol, or strong solvents to contact the screen or penetrate between the chrome brackets as permanent damage will result!

ZTechnik PO Box 158 Maywood, IL 60153-0158 USA

708-343-0400 / Fax: 708-343-0625 / www.ZTechnik.com / e mail: info@ZTechnik.com

©2003 National Cycle, Inc.

Page 1 of 1

10-117756-000 03/04